




[9] CHARGING SYSTEM



Alternator

1. Disconnect the **2P** connector (3) from alternator after turning the key switch "**OFF**".
2. Perform the following checkings.

- | | |
|-----------------------|-------------------------|
| (1) B Terminal | (3) 2P Connector |
| (2) Alternator | |

9Y1211012ELS0052US0

Connector Voltage

1. Turn the key switch "**OFF**". Measure the voltage between the **B** terminal (1) and the chassis.
2. Turn the key switch "**ON**". Measure the voltage between the **IG** terminal (3) and the chassis.

Voltage (Key switch at OFF)	B terminal – Chassis	Approx. battery voltage
Voltage (Key switch at ON)	IG terminal – Chassis	Approx. battery voltage

- | | |
|-----------------------|------------------------|
| (1) B Terminal | (3) IG Terminal |
| (2) Alternator | (4) L Terminal |

9Y1211012ELS0053US0

No-Load Test

1. Connect the **2P** connector (6) to previous positions of the alternator after turning the key switch **OFF**.
2. Connect the jumper lead (3) between **IG** terminal (4) and **B** terminal (2).
3. Start the engine and then set at idling speed.
4. Disconnect the negative cable from the battery.
5. Measure the voltage between the **B** terminal (2) and the chassis.
6. If the measurement is less than the factory specifications, disassemble the alternator and check the IC regulator.

Voltage	Factory specification	More than 14 V
---------	-----------------------	----------------

(Reference)

- Once the engine started, the alternator temperature increases quickly up to an ambient temperature of 70 to 90 °C (158 to 194 °F). As the temperature goes higher than 50 °C (122 °F), the alternator voltage slowly decreases; at higher than 100 °C (212 °F), it decreases by about 1 V.

- | | |
|-----------------------|-------------------------|
| (1) Voltmeter | (4) IG Terminal |
| (2) B Terminal | (5) L Terminal |
| (3) Jumper Lead | (6) 2P Connector |

9Y1211012ELS0054US0