

NOTE

1. When the hydraulic line is assembled, oil is applied to O-ring.
2. When the hydraulic line is assembled, prevent a thing except oil from being in the hydraulic line.
3. Confirm there is no oil leakage after assembling the hydraulic line.

4. Install filter oil cartridge.
a. Clean side where the cartridge is installed.
b. Apply oil to the side where packing of the cartridge has adhered for lubrication.
c. Tightening the torques 15 to 20 N·m { 11.07 to 14.76 lbf·ft }
5. Permissible value of the gap of the part where the oil pressure pipe is connected is 2mm or less.

