Check point	Check method	Remarks
4. High beam relay contact	1. Connect 12 V to No. 1 and 2 terminals: No. 3 and 4 terminals connected 2. No power to No. 1 and 2 terminals: No. 3 and 4 terminals open	 T46WBE7A
5. Low beam relay contact	1. Connect 12 V to No. 1 and 2 terminals: No. 3 and 4 terminals connected 2. No power to No. 1 and 2 terminals: No. 3 and 4 terminals open	 T46WBE7A