
제3각법
HEAD LIGHT(R) 55/55W
HEAD LIGHT(L) 55/55W
E/G STOP RELAY
GLOW RELAY(70A)
GLOW PLUG
OIL PRESS
C.W SENSOR
HORN
FUSE SOL
30A
FUSE CHARGE
50A
FUSE MAIN
40A
FUSE GLOW
50A
FUSE BOX
CABIN POWER
INTERRUPT
COMBINATION S/W
PANEL
START S/W
HAZARD S/W
FUEL GAUGE
EMPTY : 95Ω
HALF : 32.5Ω
FULL : 7Ω
19 30 17 50 BR AC
GLOW
OFF
ON
START
TURN/HAZARD LIGHT(R) POSITION LIGHT
STOP/TAIL LAMP
PTO LEVER S/W
SEAT S/W
STOP/TAIL LAMP
TURN/HAZARD LIGHT(L) POSITION LIGHT
TEMP BUZZER
PTO S/W
N.O
N.C
PRO S/W
BRAKE S/W
FLASH UNIT
EXT POWER
PTO SOL
ALTERNATOR
12V 50A
BATTERY
12V 50Ah
E/G STOP SOL
START RELAY
STARTER
CIRCUIT DIAGRAM
동양물산기업(주)