



UNIVERSALS

Ref. No.	Part Number	PART NAME	No. Req'd
1		TRACTOR HALF SHIELDED UNIVERSAL	
		For:	
	17-99-011	Lift Model	1
	17-99-008	Tow Model	1
2		IMPLEMENT HALF SHIELDED UNIVERSAL	
		For:	
	17-99-013	Lift Model	1
	17-99-010	Tow Model	1
		FOR YOKES ONLY ORDER:	
3	17-61-002	Tractor Shaft Yoke w/Lockpin Ass'y	
4	01-61-020	Lockpin Ass'y Only	
5	17-61-011	Implement Shaft Yoke	
		FOR SHIELD REPLACEMENT ORDER:	
		Outer Shield—Tractor Half—	
	01-61-079	Lift Model	1
	01-61-083	Tow Model	1
		Inner Shield—Implement Half—	
	01-61-084	Lift Model	1
	01-61-087	Tow Model	1
	10-61-031	Shield Bearing—All Models	2
	01-61-085	Thrust Washer—All Models	2
	01-61-086	Snap Ring—All Models	2
		FOR UNIVERSAL CENTER PARTS ORDER:	
6	17-61-004	Universal Repair Kit	2