

L5450 brochure.pdf - Adobe Reader

File Edit View Document Tools Window Help

5 / 14 200% Find

efficient speed for fieldwork between job sites.

Engine RPM	Gross Brake Power (HP)	Torque (lb·ft)	Fuel Consumption (lb/HP·h)
1200	33	145	0.40
1400	40	148	0.38
1600	48	150	0.37
1800	52	148	0.36
2000	55	145	0.36
2200	58	140	0.36
2400	60	120	0.36
2600	60	115	0.37

20 15 10
30 20

Reverse

F2803-DI (L5450)

Traveling speeds when mount

8.50 x 11.00 in

Start Eudora Torque RPM? - Mozilla Fir... Search Results L5450 brochure.pdf - ... 10:40 AM