


IGNITION SWITCH	
1	FEED (HAZ/IMPLNIT/L SWITCH)
2	DN- STEP 1 (COMB SW/ALT V/LAMP)
3	THERMOSTART
4	DN- STEP 2 (BRK SW/GAUGES)
5	START

LIGHT S	
1	MAIN
2	PARKING L
3	HEAD LIGHT

HAZARD	
1	BATTERY
2	FROM FLA



1	HAZARD SWITCH
2	BATTERY SUPPLY
3	FROM FLASHER (B)
4	HAZARD SWITCH
5	BRAKE LIGHT SWITCH
6	HEAD LIGHT (DIP BEAM)
7	HORN
8	HAZARD SWITCH
9	PARKING LIGHTS
10	ILLUMINATION INST.

1	HAZARD SWITCH
2	BATTERY SUPPLY
3	FROM FLASHER (B)

1	HAZARD SWITCH
2	IMPLEMENT LAMP
3	HAZARD SWITCH
4	HAZARD SWITCH
5	BRAKE LIGHT SWITCH
6	HEAD LIGHT (DIP BEAM)
7	HORN
8	HAZARD SWITCH
9	PARKING LIGHTS
10	ILLUMINATION INST.

