

Jinma Wiring Diagram

The following diagram is for Jinma tractors.
It is slightly updated from the diagrams that
come in the Chinese manual.

Farm Boss Tractors




Fig. 6-1 Electrical Wiring Diagram

1. Battery 2. Horn 3. Front Headlight 4. Headlight connectors 5. Alternator 6. Starter 7. Fuse Box 8. Taillights & Work Light Switch 9. Rear Tail/Signal Lights 10. Work Light Connector 11. Rear Work Light 12. Ammeter 30Amp 13. Ignition Switch 14. Horn Relay 15. Horn Button 16. Headlight Switch 17. Turn Signal Switch 18. Oil Pressure Gauge 19. Voltage Regulator 20. Flasher 21. Tachometer /Hour meter /Speedometer 22. Water Temperature Gauge 23. Fuel Gauge 24. Oil Pressure Sender 25. Water Temperature Sender 26. Fuel Gauge Sender 27. Glow Plugs 28. Clutch /Starter Safety Switch 29. Brake Light Switch 30. Tachometer Sender

Copyright © 2001 Tractor Outlet

Above diagram provided, courteous of
Tractor Outlet