

John Deere Ballast Calculator

3X20 BALLAST CALCULATOR

			Lb./Front	Lb./Rear
Tractor Model	3328		1173	1302
Operator	43816		47	143
Operator's Station	Open Station		0	0
Front Tire Size	27.5-15.5 SPS R4 G6		101	0
Rear Tire Size	15.5R-15.5 SPS R4 G6		0	370
Base Tractor Weight (w/operator)			1327	1815
Loader	No Loader		0	0
iMatch	n/a iMatch		0	0
Rear Attachment	No Attachment		0	0
Tractor Weight with Attachment			1327	1815
Fluid in Front Tires	No Fluid in Tires		0	0
Fluid in Rear Tires	No Fluid in Tires		0	0
Front Weight Bracket	No Bracket		0	0
Front Weight Used	RSS345 (421L)		0	0
Qty. of Front Weights	0		0	0
Rear Tire Weights (per side)	No Rear Wheel Weight		0	0
Ballasted Tractor Weight			1327	1815
Total Weight			3143	
			Front	Rear
			42%	58%

- Attachment Compatibility
- Operator's Manual
- Back