



FUSE(MAIN) DETAILS	
(a) 15A	MAIN
(b) 10A	HAZARD(TURN) LAMP
(c) 10A	ALTERNATOR, GLOW CONTROLLER, ELECTROMAGNET PUMP, TURN SIGNAL, PANEL INDICATOR
(d) 10A	ETR sol(HOLD)
(e) 10A	HEAD LAMP, TAIL LAMP
(f) 10A	EXTRA POWER SUPPLY



