

NO.	Dashboard Fault Code	Fault Code	Warning Lamp		Title
			AMB	RED	
100	s651 F05 s651 F06	P0201		Solid on	Injector 1 Circuit fault
101	s653 F05 s653 F06	P0203		Solid on	Injector 2 Circuit fault
102	s654 F05 s654 F06	P0204		Solid on	Injector 3 Circuit fault
103	s652 F05 s652 F06	P0202		Solid on	Injector 4 Circuit fault
104	s675 F03 s675 F05 s675 F06 s675 F31	P2687	Solid on		Fuel Heater Driver fault
105	s174 F02	P0201		Solid on	Fuel temp sensor gradient fault
106	s174 F03	P0183		Solid on	Fuel temp sensor high fault
107	s174 F03	P0182		Solid on	Fuel temp sensor low fault
108	s676 F05	P0380	Solid on		GP relay open circuit fault
109	s676 F04	P0383	Solid on		GP relay short circuit to ground fault
110	s676 F03	P0384	Solid on		GP relay short circuit to source fault
111	s1076 F31	P0254		Solid on	IMV current trim drift fault
112	s157 F11 s1076 F03 s1076 F04 s1076 F16 s1076 F18	P0002		Solid on or 1 Hz	IMV control fault
113	s1076 F03	P0004		1 Hz	IMV control feedback high fault
114	s1076 F04	P0003		Solid on	IMV control feedback low fault
115	s1076 F05	P0001		1 Hz	IMV driver signal open circuit fault
116	s172 F02	P0074		Solid on	Inlet Air Temp sensor signal gradient fault
117	s172 F03	P0073		Solid on	Inlet Air Temp sensor signal high fault
118	s172 F04	P0072		Solid on	Inlet Air Temp sensor signal low fault
119	s5202 F31	U0140	Solid on		CAN message Time-out fault
120	s106 F03 s106 F04	P0106		Solid on	Intake Manifold Absolute Pressure sensor signal drift fault
121	s106 F03	P0108		Solid on	Intake Manifold Absolute Pressure sensor signal high fault
122	s106 F04	P0107		Solid on	Intake Manifold Absolute Pressure sensor signal low fault
123	s0651 F31	P029B	Solid on		Injector 1 MDP value low fault
124	s653 F31	P02A3	Solid on		Injector 2 MDP value low fault
125	s654 F31	P02A7	Solid on		Injector 3 MDP value low fault