

MASSEY FERGUSON®

DL100

4283255M3
CONTENTS

1	SAFETY
1	GENERAL INFORMATION
1	SAFETY ALERT SYMBOL
2	SIGNAL WORDS
3	SAFETY RULES
10	SAFETY SIGNS AND LOCATIONS
13	INTRODUCTION
13	General Information
14	Identification
14	Model and Serial Number
14	Front References
15	OPERATION
15	TRACTOR Ballast
15	Tire Tread Width
16	TRACTOR/Loader HYDRAULIC CONTROLS
16	TRACTOR Mounted Joystick Control Lever
17	Pedestal Mounted Joystick and Auxiliary Valve
18	Prepare Tractor Hydraulics
19	Using Tractor Mounted Joystick
20	TRACTOR Mounted Joystick Lockout
21	Using Loader Mounted Joystick
21	Loader Raise/Lower
21	Loader Float Position
21	Bucket Roll Back/Dump
22	Install Loader On Tractor
22	Preliminary Checks and Preparation
23	Install Loader
23	Connect Loader Hoses to Tractor Couplers
24	Connect Loader Hoses to Pedestal Mounted Auxiliary Valve
24	Roll Loader Onto Pedestal Mounts
26	Install Rear Ballast
27	Final Adjustment
27	Loader Mounting Frame Attaching Hardware
27	TRACTOR Wheel Mounting Hardware
28	Hydraulic Oil Level
30	Basic Loader Operation
30	Installing and Removing Attachments
32	Standard Pin Attach
35	Remove Loader From Tractor
35	Disconnect Hoses From Loader
37	Remove Rear Ballast From Tractor
37	LUBRICATION AND MAINTENANCE
37	Lubrication Points
38	Hydraulic System
38	Hoses and Cylinders
39	Hydraulic Cylinder Repair
39	Check Loader Frame Hardware
40	Hardware Tightening Chart
40	Troubleshooting
41	Store Loader
41	SPECIFICATIONS
41	Example - MF DL100 Standard Loader on GC2400 4WD Tractor