




General Notes:

1. Timber frame is designed according to the 2009 International Building Code design load values.
2. Glazing for windows specified as stated according to the 2009 IBC using ANSI Z99.1 Classifications.
3. Verify all window and door design with applicable local codes.
4. Solid blocking must be installed under every post location before the timber frame is raised. See the included subfloor plan for post locations and sizes.
5. If a decorative edge is desired on the timbers, the choice must be made before the timber frame is cut. The locations of decorative edges are shown on our website under "Decorative Edges" on the "Building Details" page.
6. Normally the timber is finished with a coat of boiled linseed oil. If the timber needs to be unfinished, Clydesdale Frames must be notified before the timber frame is cut.
7. Explanations of many construction issues with a timber frame can be found on our website's "Building Details" page.
(www.clydesdaleframes.com)



Printed:	03/19/2013	Project:	Jeremy & Stacy Kovac
Last Revision:	03/19/2013	Location:	St. Joe, Missouri

Clydesdale Frames Co.
610 N. Clydesdale Dr.
Hutchinson, KS 67501

www.clydesdaleframes.com
john@clydesdaleframes.com
chris@clydesdaleframes.com