

# ASSEMBLY

## Attaching Snowblower to Tractor (Figure 7)

1. Move quick hitch lever (item 9) rearward to unlock position.
2. Install the male driveline (item 2), supplied with the drive kit, on snowblower female driveline (item 3) and support with the driveline support (item 1).
3. Position tractor behind snowblower and raise male quick hitch approximately 3/4" from the ground.
4. Introduce male quick hitch (item 4) into female hitch (item 5) on blower. Raise male section so that it is parallel to female section and insert it all the way into female section. Raise blower and move the lever (item 9) forward to locked position. Secure latch (item 7) with linch pin (item 6).
5. Connect male driveline (item 2) to subframe drive shaft (item 8) by sliding back locking collar on driveline yoke and pushing yoke over shaft until locking ring snaps back and push driveline support down (item 1).



### CAUTION:

To avoid serious personal injuries: Make sure that the driveline quick coupler is securely locked in place. A "click" must be heard. If it is not securely fastened, it will come off the spindle shaft and spin out of control.



### WARNING:

#### **To avoid serious personal injuries:**

This shaft turns at up to 2000 RPM. If the collar is not locked to the shaft at tractor end, or if the yoke at the blower end is not secured properly, the driveline can fly loose with great force capable of causing serious injury or death.

6. Adjust skid shoes according to adjustment instructions in the **OPERATION** section.

## Removing Snowblower from Tractor (Figure 7)

1. Park tractor/snowblower on level ground, place all control levers in neutral, set the parking brake, shut off the engine and remove the ignition key.
2. Remove the rotation handle (Fig. 6a, item 2) from the handle support (Fig. 6a, item 3)
3. Remove linchpin (item 6) from male hitch latch and place male hitch lever (item 8) rearward to unlock position.
4. Disconnect male driveline (item 2) from subframe drive shaft. Set driveline on its support and remove snowblower.




Figure 7